



NOTES:

1. REMOVE METAL PARAPET CAP, INSTALL FLASHING, AND REINSTALL METAL.



METAL PARAPET CAP COPING AND BASE FLASHING

BUR - 9
Acrylic 264
NOT TO SCALE